



Cameo China

Pure White Collection

純白系列



RIM PLATE 平盤

210-61	6.25"	(16cm)
210-71	7.25"	(18.5cm)
210-81	8.25"	(21cm)
210-91	9.25"	(23.5cm)
210-111	10.25"	(26cm)
210-111D	11"	(28cm)



COUPE PLATE 月光盤

210-51N	5"	(13cm)
210-61N	6"	(15cm)
210-71N	7"	(18cm)
210-81N	8"	(20cm)
210-91N	9"	(23cm)
210-111N	10.25"	(26cm)
210-121	12"	(30.5cm)
210-141	14"	(35.5cm)
210-161	16"	(40.5cm)



OVAL PLATTER 長盤

210-83	8.25"	(21cm)
210-93	9.25"	(23.5cm)
210-03	10.25"	(26cm)
210-113	11.25"	(28.5cm)
210-23	12"	(30.5cm)
210-43	14"	(35.5cm)
210-63	16"	(40.5cm)



SQUARE PLATE 方盤

710-71N	7.5"	(19cm)
710-101N	10"	(25.5cm)



ROUNDED SQUARE PLATE 方圓盤

712-71N	7.25"	(18.5cm)
712-91N	9.25"	(23.5cm)
712-101N	10.25"	(26cm)



RECTANGULAR PLATTER 長皿

710-83	8.5"	(21.5cm)
710-103A	10.5"	(27cm)



HANDLED RECT. PLATTER 翹邊長皿

710-93S	8.5"	(21.5cm)
---------	------	----------



NARROW RECT. PLATTER 長條皿

710-103	10.25"	(26cm)
---------	--------	--------

Pure White Collection 純白系列



RICE BOWL 直口飯碗
210-99 4.5" (11.5cm)



RICE BOWL 反口飯碗
210-99B 4.5" (11.5cm)



RICE BOWL SAUCER 直口飯碗底碟
210-80S 6" (15cm)



SMALL BOWL 直口小碗
210-89 4" (10cm)



SMALL BOWL 反口小碗
210-59 3.75" (9.5cm)



SOUP BOWL 反口湯碗
210-164 6" (15cm)
210-174 7" (18cm)
210-184 8" (20cm)
210-194 9" (23cm)



SOUP BOWL 直口湯碗
210-74 7.25" (18.5cm)
210-84 8.25" (21cm)
210-94 9.25" (23.5cm)



FOOTED BOWL 高足碗
210-L99 4.5" (11.5cm)
210-L99A 5" (13cm)
210-L64 6" (15cm)



COUPE BOWL 直口淺碗
610-1013 5" (13cm)
610-1015 6" (15cm)
610-1018 7.25" (18.5cm)
610-1020 8" (20cm)
610-1023 9" (23cm)



RAMEN BOWL 波浪麵碗
710-184R 8" (20cm)
710-194R 9" (23cm)



NOODLE BOWL 斗形麵碗
710-174 7" (18cm)
710-184 8" (20cm)



ROUNDED SQUARE BOWL 方圓碗
712-64 6.75" (17cm)
712-74 7.5" (19cm)
712-84 8.25" (21cm)



SQUARE BOWL 方碗
710-334 4.5" (11.5cm)
710-389 6" (15cm)
710-974 6.75" (17cm)
710-975 7.5" (19cm)



BOWL 直口碗
710-205 5" (13cm)



DIP BOWL 調味碗
710-59 4" (10cm)



DEEP BOWL 飯盅
210-346 4.25" (11cm)



POT WITH LID 蓋盅
210-344 4" (10cm)



POT WITH LID 蓋盅
210-40 4.5" (11.5cm)



BOWL WITH LID 蓋碗
210-3264 6.25" (16cm)



CASSEROLE 湯煲
210-274 8" (20cm)
210-204 10" (25.5cm)



Pure White Collection 純白系列



ROUND DISH 圓碟

210-31 3" (7.5cm)
210-41 3.75" (9.5cm)



DIM SUM DISH 點心碟

210-42A 4.5" (11.5cm)



ROUND DISH 圓碟

710-22A 3.5" (9cm)



DIVIDED DISH 兩格碟

210-013 3" (7.5cm)



SQUARE DISH 方碟

710-885 3.375" (8.5cm)



DEEP SQUARE DISH 方深碟

710-1552 3.25" (8cm)



RECTANGULAR DISH 長方碟

710-41 3.75" (9.5cm)



ROUND SERVING DISH 泡菜碟

710-125 6" (15cm)



DIVIDED RECT. DISH 三格碟

710-2010 8.75" (22cm)



SPOON 湯匙

210-08 5.25" (13.5cm)



SPOON 長把湯匙

210-08H 6" (15cm)



DIVIDED ROUND DISH 五格碟

210-555 13" (33cm)



CHOPSTICK REST 長條筷子架

210-60 2.5" (6.5cm)



OVAL CHOPSTICK REST 橢圓筷子架

710-60 1.75" (4.5cm)



PANDA CHOPSTICK REST 熊貓筷子架

210-60P 2.5" (6.5cm)
Hand Painted 手工繪製



WEDDING CHARGER PLATE 婚宴秀盤

666-101S 9.75" (25cm)

Pure White Collection 純白系列



TEAPOT 茶壺

210-15PL 400ml
210-25PL 650ml
210-16PL 900ml



TEAPOT 高身茶壺

210-26PL 1,050ml



TEAPOT LID 茶壺蓋

210-15LD 400ml Teapot
210-25LD 650ml Teapot
210-16LD 900ml Teapot



TEAPOT WARMER 茶壺暖爐

210-W16 5" (13cm)



CHINESE TEACUP 無把茶杯

210-29 140ml



TEACUP SAUCER 茶杯底碟

210-29S 4" (10cm)



JAPANESE TEACUP 日式茶杯

710-19 150ml



JAPANESE TEACUP 日式茶杯

710-29 200ml



CUP & SAUCER 有把茶杯碟

210-49C 150ml
210-49S 5.25" (13.5cm)



STACKING CUP & SAUCER 可疊咖啡杯碟

210-038 200ml
210-040 6" (15cm)



ESPRESSO CUP & SAUCER 濃咖啡杯碟

210-041 125ml
210-042 5.25" (13.5cm)



SAKE CUP 清酒杯

710-69 50ml



SAKE CUP 清酒杯

710-69A 50ml



SAKE POT 清酒壺

710-36 150ml



SAKE POT 清酒壺

710-36A 240ml



SOY SAUCE POT 日式醬油壺

710-15 150ml



SOY SAUCE POT 醬油壺

210-30S 100ml



TABLE VASE 花瓶

210-R015 5" (13cm)



SALT/PEPPER SHAKER 鹽/胡椒罐

210-R021S/P 2.75" (7cm)



TOOTHPICK HOLDER 牙籤筒

210-50 2.25" (5.5cm)



Blue Lotus Collection 藍花系列



POT WITH LID 蓋盅

255-344 4" (10cm)



POT WITH LID 蓋盅

255-40 4.5" (11.5cm)



BOWL WITH LID 蓋碗

255-3264 6.25" (16cm)



CASSEROLE 湯煲

255-274 8" (20cm)
255-204 10" (25.5cm)



RIM PLATE 平盤

255-61	6.25"	(16cm)
255-71	7.25"	(18.5cm)
255-81	8.25"	(21cm)
255-91	9.25"	(23.5cm)
255-111	10.25"	(26cm)
255-111D	11"	(28cm)



COUPE PLATE 月光盤

255-121	12"	(30.5cm)
255-141	14"	(35.5cm)
255-161	16"	(40.5cm)



OVAL PLATTER 長盤

255-83	8.25"	(21cm)
255-93	9.25"	(23.5cm)
255-03	10.25"	(26cm)
255-113	11.25"	(28.5cm)
255-23	12"	(30.5cm)
255-43	14"	(35.5cm)
255-63	16"	(40.5cm)

Blue Lotus Collection 藍花系列



RICE BOWL 直口飯碗

255-99 4.5" (11.5cm)



RICE BOWL 反口飯碗

255-99B 4.5" (11.5cm)



RICE BOWL SAUCER 直口飯碗底碟

255-80S 6" (15cm)



SMALL BOWL 反口小碗

255-59 3.75" (9.5cm)



SOUP BOWL 反口湯碗

255-164 6" (15cm)
255-174 7" (18cm)
255-184 8" (20cm)
255-194 9" (23cm)



SOUP BOWL 直口湯碗

255-74 7.25" (18.5cm)
255-84 8.25" (21cm)
255-94 9.25" (23.5cm)



DIVIDED ROUND DISH 五格碟

255-555 13" (33cm)



TEAPOT 茶壺

255-15PL 400ml
255-25PL 650ml
255-16PL 900ml



CHINESE TEACUP 無把茶杯

255-29 140ml



CUP & SAUCER 有把茶杯碟

255-49C 150ml
255-49S 5.25" (13.5cm)



STACKING CUP & SAUCER 可疊咖啡杯碟

255-038 200ml
255-040 6" (15cm)



ESPRESSO CUP & SAUCER 濃咖啡杯碟

255-041 125ml
255-042 5.25" (13.5cm)



SOY SAUCE POT 醬油壺

255-30S 100ml



VINEGAR POT 醋壺

255-30V 100ml



ROUND DISH 圓碟

255-31 3" (7.5cm)
255-41 3.75" (9.5cm)



SPOON 湯匙

255-08 5.25" (13.5cm)



SALT/PEPPER SHAKER 鹽/胡椒罐

255-R021S/P 2.75" (7cm)



TOOTHPICK HOLDER 牙簽筒

255-50 2.25" (5.5cm)



CHOPSTICK REST 長條筷子架

255-60 2.5" (6.5cm)



ASHTRAY 煙灰缸

255-32 3.75" (9.5cm)

Imperial Dragon Collection 龍行天下系列



RIM PLATE 平盤

288-61	6.25"	(16cm)
288-71	7.25"	(18.5cm)
288-81	8.25"	(21cm)
288-91	9.25"	(23.5cm)
288-111	10.25"	(26cm)
288-111D	11"	(28cm)



COUPE PLATE 月光盤

288-71N	7"	(18cm)
288-81N	8"	(20cm)
288-91N	9"	(23cm)
288-111N	10.25"	(26cm)
288-121	12"	(30.5cm)
288-141	14"	(35.5cm)
288-161	16"	(40.5cm)



OVAL PLATTER 長盤

288-83	8.25"	(21cm)
288-93	9.25"	(23.5cm)
288-03	10.25"	(26cm)
288-113	11.25"	(28.5cm)
288-23	12"	(30.5cm)
288-43	14"	(35.5cm)
288-63	16"	(40.5cm)

Imperial Dragon Collection 龍行天下系列



RICE BOWL 直口飯碗

288-99 4.5" (11.5cm)



RICE BOWL 反口飯碗

288-99B 4.5" (11.5cm)



RICE BOWL SAUCER 直口飯碗底碟

288-80S 6" (15cm)



SMALL BOWL 反口小碗

288-59 3.75" (9.5cm)



SOUP BOWL 反口湯碗

288-164 6" (15cm)
288-174 7" (18cm)
288-184 8" (20cm)
288-194 9" (23cm)



SOUP BOWL 直口湯碗

288-74 7.25" (18.5cm)
288-84 8.25" (21cm)
288-94 9.25" (23.5cm)



BOWL 直口碗

288-64 6" (15cm)



DEEP BOWL 飯盅

288-346 4.25" (11cm)



BOWL WITH LID 蓋碗

288-3264 6.25" (16cm)



CASSEROLE 湯煲

288-204 10" (25.5cm)



DIVIDED ROUND DISH 五格碟

288-555 13" (33cm)



TEAPOT 華式茶壺

288-19PL 1,050ml



TEAPOT 茶壺

288-15PL 400ml
288-25PL 650ml
288-16PL 900ml



CHINESE TEACUP 無把茶杯

288-29 140ml



CUP & SAUCER 有把茶杯碟

288-49C 150ml
288-49S 5.25" (13.5cm)



STACKING CUP & SAUCER 可疊咖啡杯碟

288-038 200ml
288-040 6" (15cm)



ROUND DISH 圓碟

288-31 3" (7.5cm)
288-41 3.75" (9.5cm)



DIVIDED DISH 兩格碟

288-013 3" (7.5cm)



SPOON 湯匙

288-08 5.25" (13.5cm)



CHOPSTICK REST 長條筷子架

288-60 2.5" (6.5cm)

Koi Fish Collection

鯉魚系列



RIM PLATE 平盤

182-P81 8" (20cm)
182-P111 10.5" (27cm)



COUPE PLATE 月光盤

182-P71N 7" (18cm)
182-P121 12" (30.5cm)



RICE BOWL 飯碗

182-P99 4.5" (11.5cm)



RICE BOWL 波紋飯碗

182-P99B 4.5" (11.5cm)



SOUP BOWL 湯碗

182-P174 7" (18cm)
182-P184 8" (20cm)



DEEP PLATE 深盤

182-P168 8" (20cm)



TEAPOT 茶壺

182-P16 900ml



CHINESE TEACUP 無把茶杯

182-P29 130ml



ROUND DISH 圓碟

182-P31 3" (7.5cm)



SPOON 湯匙

182-P08 5.25" (13.5cm)



CHOPSTICK REST 魚形筷子架

182-P60 2.5" (6.5cm)



BAMBOO CHOPSTICKS 竹筷

182-CH11 9" (23cm)

Graphite Collection

黑釉系列



FOOTED BOWL 高足碗

910-L99	4.5"	(11.5cm)
910-L99A	5"	(13cm)
910-L64	6"	(15cm)



COUPE BOWL 直口淺碗

910-1013	5"	(13cm)
910-1015	6"	(15cm)
910-1018	7.25"	(18.5cm)



RAMEN BOWL 波浪麵碗

910-7184R	8"	(20cm)
910-7194R	9"	(23cm)



SQUARE PLATE 方盤

910-771N	7.5"	(19cm)
----------	------	--------



RECTANGULAR PLATTER 長皿

910-783	8.5"	(21.5cm)
---------	------	----------



NARROW RECT. PLATTER 長條皿

910-7103	10.25"	(26cm)
----------	--------	--------



COUPE PLATE 月光盤

910-271N	7"	(18cm)
910-281N	8"	(20cm)



ROUND DISH 圓碟

910-722A	3.5"	(9cm)
----------	------	-------



SQUARE DISH 方碟

910-7885	3.375"	(8.5cm)
----------	--------	---------



DEEP SQUARE DISH 方深碟

910-71552	3.25"	(8cm)
-----------	-------	-------



RECTANGULAR DISH 長方碟

910-741	3.75"	(9.5cm)
---------	-------	---------



SAKE POT 清酒壺

910-736	150ml
---------	-------



SAKE POT 清酒壺

910-736A	240ml
----------	-------



SAKE CUP 清酒杯

910-769	50ml
---------	------



SAKE CUP 清酒杯

910-769A	50ml
----------	------



DIP BOWL 調味碗

910-759	4"	(10cm)
---------	----	--------



JAPANESE TEACUP 日式茶杯

910-719	150ml
---------	-------



SOY SAUCE POT 日式醬油壺

910-715	150ml
---------	-------



OVAL CHOPSTICK REST 橢圓筷子架

910-760	1.75"	(4.5cm)
---------	-------	---------

Fine Bone China Collection

高級骨瓷系列



COUPE PLATE 月光盤

510-71N	7"	(18cm)
510-81N	8"	(20cm)
510-91N	9"	(23cm)
510-101N	10"	(25.5cm)



RICE BOWL 飯碗

510-99	4.5"	(11.5cm)
--------	------	----------



ROUND DISH 圓碟

510-31	3"	(7.5cm)
510-41	3.75"	(9.5cm)



CHINESE TEACUP 無把茶杯

510-29	140ml
--------	-------



TEACUP SAUCER 茶杯底碟

510-29S	4"	(10cm)
---------	----	--------



SPOON 湯匙

510-08	5.25"	(13.5cm)
--------	-------	----------



Cameo China

D u r a b l e

